JJ-RC-SM20E(DBCN) INSTRUCTION V1.0

Technical data:

• Frequency: 433.92MHZ

• Range of frequency deviation: ± 130 KHZ

• Range of working voltage: 7.5-12V

Battery: 27A

● Working current: 12mA±2mA

Static current: 0uA

• Code: DOORHAN, BFT MITTO, CAME, NICEFLORS

• Distance: 100m in an open area

Operate instruction:

Brand changing:

Press the 1st and 2nd button at the same time, the LED light will flash once and then go off. About 3 seconds later, the LED light will be on again, which means that it has entered into the selection state. This moment please keep pressing the 1st button and release the 2nd button, the LED light will go off. After above all operation, brand changing depends on the times to press 2nd button. Details are as following:

- (1) Press the 2nd button once continuously, and the LED light flashes once. It means DOORHAN brand is setting successfully.
- (2) Press the 2nd button twice continuously, and the LED light flashes twice. It means BFT MITTO brand is setting successfully. Press 4 buttons

at the same time to launch seed code.

- (3) Press the 2nd button 3 times continuously, and the LED light flashes twice. It means CAME brand is setting successfully.
- (4) Press the 2nd button 4 times continuously, and the LED light flashes 4 times. It means NICEFLORS brand is setting successfully.

